

*Fast*Tracer

The Triaxial Portable USB Vibration Analyzer



Contents

- FastTracer USB Portable Analyser
- What Is FastTracer
- FastTracer Features
- FastTracer Software
 - FFT analysis, Time Analysis, Excel Reporting, SO 10816 RMS evaluation, Trigger View (Bump Test), Time Data Recording
- Application Field
- Application Case
- Advanced Feature : FastWi
- Advanced Feature: Explora 3D (Beta Version)
- Advanced Feature: PA (Open Protocol)



FastTracer the portable USB analyser

*Fast*Tracer thanks to:

-High Performance -Extreme reliability -Simplicity to use



make vibration analysis a simple task also for non expert operators.

Simply connect *Fast*Tracer to your PC via the USB port to turn it into a powerful Triaxial Vibration Analyser.

With *FastTracer* you can easy handle several vibration problem within maintenance program, troubleshooting, quality control, R&D and design activities.



What is FastTracer ?

*Fast*Tracer it's an "all in one" solution that include within a single transducer all you require from a powerful Triaxial Vibration Analyser:





FastTracer Features (1)

Sensor Specification:

Full scale Bandwith Comunication Protection Index Shock resistance Operating Temperature 5g (or optional 2g and 18g)* 0 – 2500 Hz USB 2.0 or WiFi** IP67 10.000 g -20 / 70°C



*the 18g option is suited for high vibration level while the 2 g option with low noise is suitable for very low level (eg. Building Vibration)

** Using the FASTWI Option



FastTracer Features (2)

The compact solution it's possible thanks to the sensing elements realized with **MEMS** (Micro Electro-Mechanical Systems) technology. This leads to several advantages compare to other classical solution such as:

Long Term stability of MEMS and DC Reaing

Digitalization within Trasducer

Technically no periodical calibration it's required. You can further be sure of the correct reading by comparing measurement against gravity acceleration of 9,81 g. No portable calibration required !!

Signal are digitized directly within the transducer. This imply that the signal transmitted it's not effected by cable triboelectric noise. Your data are therefore more reliable and precise.

High Shock (10.000 g) and IP67 Drop it or even lunch against hard surface. You would not break it. This, together with the high protection level, allow the usage of the FastTracer in the most demanding environmental condition



FastTracer Features (3)

FastTracer it's high precision measuring system. Each unit it's delivered with it's

own individual calibration cerfificate fully traceable to **INRIM**, the primary Italian metrological institute.

Each *Fast*Tracer is internally fully «balanced». When you connect the unit to the PC, the software automatically detect it and you can start measureament without any further setup:

levices	×
 Devices USB FastTracer 5g - SQ-S-047022 Data 	
Id: FastTracer	
PN: 50130038	
Rev: V4.0	
Device Info	
Sample Rate: 8192	
Full Scale: 5g	

() SEQUC	AIC	FastTra	acer	
Calibration Certifi	icate			
FastTracer:	S.N 50-5-140001	Full Range ±	5 g	
has been individua nstitute INRIM.	ally calibrated in the internationa	illy recognized metri	rological	
Calibration result	ts':			
Axis X: 37.				
Axis Y: 2%	± 2 %, @ 159,16 Hz and sign	al amplitude of 10 r	m/s ²	
Axis Z: 4%	- 2 70, @ 109,10 he did sign	an amplitude of 10 h		
)			
The whole set of r	measurements realized in INRIM B Flash Memory contained in the F	l laboratories is loa astTracer case.	ded into	
and bequere in the				
				10000
25/11/4	14 Sig	Da		10000 g
Date 25/41/4	11 Sign	Dg		
Date 25/44/4	14 Sign	- Dg		
¹ Calibration is traceabl	LL Sign	ð	measured	-20 ÷ 70 °
¹ Calibration is traceabl		ð	measured -	-20 ÷ 70 ° Units
¹ Calibration is traceable and reference value.	ile to INRIM, Italy. Results are expressed as	F	measured	-20 ÷ 70 ° Units %
¹ Calibration is traceable and reference value.		s relative error between r	measured -	-20 ÷ 70 ° Units %
¹ Calibration is traceable and reference value.	ile to INRIM, Italy. Results are expressed at Seguola IT s.r.l. Via Einaudi 25, Moncalieri	s relative error between r	neasured	-20 ÷ 70 ° Units % % m/s ²
¹ Calibration is traceable and reference value.	ile to INRIM, Italy. Results are expressed at Seguola IT s.r.l. Via Einaudi 25, Moncalieri	s relative error between r	neasured -	-20 ÷ 70 ° Units % % m/s ² m/s ²
¹ Calibration is traceable and reference value.	ile to INRIM, Italy. Results are expressed at Seguola IT s.r.l. Via Einaudi 25, Moncalieri	(TO) - ITALY www.sequola.it	3	-20 + 70 * Units % % m/s ² m/s ²
¹ Calibration is traceable and reference value.	de to /NRIM, Italy. Results are expressed as Sequels IT c.r.l. Via Einaudi 25, Moncalleri et. +39 011 6402992 - info@sequela.it - w Change due to	(TO) - ITALY www.sequola.it Density	1'2 × 10	-20 ÷ 70 ⁴ Units % % m/s ² m/s ² m/s ² / _{Hz}
¹ Calibration is traceable and reference value.	de to /NRIM, Italy. Results are expressed as Sequels IT c.r.l. Via Einaudi 25, Moncalleri et. +39 011 6402992 - info@sequela.it - w Change due to	(TO) - (TALY www.sequola.it oensity Amplitude On full temp	1,3 × 10-	-20 + 70 4 Units % % % m/s ² m/s ² m/s ² /vHz %/°C
¹ Calibration is traceable and reference value.	de to /NRIM, Italy. Results are expressed as Sequels IT c.r.l. Via Einaudi 25, Moncalleri et. +39 011 6402992 - info@sequela.it - w Change due to	(TO) - ITALY www.sequola.it versity Amplitude On full temp range	1,5 × 10	-20 ÷ 70 ° Units % % m/s ² m/s ² m/s ² /fiz %/°C
and reference value.	de to /NRIM, Italy. Results are expressed as Sequels IT c.r.l. Via Einaudi 25, Moncalleri et. +39 011 6402992 - info@sequela.it - w Change due to	(TO) - (TALY www.sequola.it Density Amplitude On full temp range Offset On full temp	0,01 0,5 6 × 10 ⁻³	-20 + 70 ° Units 96 96 96 96 96 96 96 96 96 96
¹ Calibration is traceable and reference value.	de to //NRIM, Italy. Results are expressed as Sequels IT c.r.L. Via Einaudi 25, Moncalient et, +39 011 6402992 - info@sequela.it - w Change due to temperature Minimum mounting	(TO) - (TALY www.sequola.it vensity Amplitude On full temp range Offset On full temp range Magnetic fixture	1,5 × 10 0,01 0,5 6 × 10 ⁻³ 0,27 200	-20 + 70 * Units % % % m/s ² m/s ² m/s ² %/ ⁵² % % m/s ² /% % m/s ² /% m/s ² % m/s ² m/s ²
¹ Calibration is traceable and reference value.	de to INRIM, Maiy. Results are expressed at Sequola IT s.r.t. Via Einaudi 25, Moncalieri et 39 011 6402992 - info@sequola.it - w Change due to temperature Minimum mounting diameter - ' Te-25'C, Signel amplitude: 0 Sequola	(TO) - (TALY www.sequola.it vensity Amplitude On full temp range Offset On full temp range Magnetic fixture	1,5 × 10 0,01 0,5 6 × 10 ³ 0,27 200 mited with 4 screws a	-20 + 70 4 Units % % m/s ² m/s ² m/s ² % % m/s ² /fiz % m/s ² /c m/s ² m/s ²

FastTracer Software

FFT Analysis:

Bandwidth : DC – 2500 Hz
Point: up to 524288 (High Frequency Resolution)
Acceleration, Velocity and Displacement result
Automatic Peak Cursor







FastTracer Software Time Analysis

Time Analysis:

Whenenver you are measuring long time data it's always «stored» within RAM of you PC so you would not lost any data along with your measure. You can select any portion of the time signal for investigation purpose or the export it to Excel for automatich reporting.





FastTracer Software Excel Reporting (1)

Excel Reporting

The automatic excel reporting its an advanced tool. Trough exel reporting, in a a matter of few seconds data are not only transferred to excel but several calculation are performed:

m/s ² 13747 samples 0.0:1.67 Acceleration X[m/s ²] avrg:-0.094 min:-3.225 max:2,924 pk-pk:6,149			,							
Acceleration 2(m/s) engls/spc times/spc times/				1	Align	tom of G e cell.	Н	1	J	K
				vidth					5	IX.
				500,00	Reloa	d Data				
)					NA / 7	79.47	VD 1		70 / 1	
				nm/s] 58683	YV [mm/s] 0.963079	2V [mm/s] -0.39935	XD [µm] 0.590603	YD [µm]	ZD [µm] -6,79669	RMS XV [mm/s] 0.0991767
				46548	0,963079	0,39935	0,590603	2,18191 1,53864	-6,96937	0,0991767
- Wrown my monor phin when when the	Malan	union	min	·····1.3645	0,843111	-0,556422	0,432621	0.900995	-6,96937	0,159338
	NY M	- Mummi	www.edlar	27634	0,372027	-0.652995	0.0830424	0.268739	-7,33395	0,133330
•••••••••••••••••••••••••••••••••••••••				1,1903	-0.109459	-0.756745	-0.106739	-0.356373	-7.5247	0,192519
	Exp	ort to text file		11014	-0,3	-,	-,	0,000000	.,	287
e MMM Marken Marin Manus Marin Mary an		ort to spreadsheet		03097		eload t	he dat	ta into	excell	
		e oscilloscope imag		54484	-0,7				CAUCII	2159
5		t oscilloscope imag	e	379573	-0,8 DE	erfom	all	the	avai	lable 1887
o 🔪	Ken	nove Selection		05568	-1 PC		an	uic	avai	:947
				19091	-1 ca	Iculatio	n			5796
go 2000 1900 1800 1700 1600 1500 1400 1300 1200 1100 1000 900 800		00 500 40		00 130372)594
0,4	447599	-3,02115	-9,54094	0,54258	-1,59276	-1,7915	-1,92875	-5,07449	-9,1601	0,241519
Salast the partian of assuminition	72223	-3,06039	-9,54141	0,444047	-1,75692	-1,92549	-2,19207	-5,62321	-9,36221	0,242639
Select the portion of acquisition)5936 }3351	-3,13711 -3,13638	-9,65908 -9,6981	0,342592	-1,9148 -2.06178	-2,06841 -2,20978	-2,46189 -2,73722	-6,16024 -6.68477	-9,56129 -9,75594	0,243109 0,243119
you would like to applyze with)5025	-3,13636	-9,77628	0,245652	-2,06176	-2,20976	-2,73722	-0,00477	-9,75594	0,243119
ou would like to analyze with	19285	-3.21354	-9.81545	0.0326987	-2,20433	-2,49929	-3,3044	-7,69563	-10,1285	0,242000
avoid report and aligh	18192	-3.2891	-9.97247	-0.0735623	-2,47697	-2.65333	-3,59466	-8,18105	-10,3045	0,24191
excel report and click	54696	-3.32586	-10.1287	-0.181495	-2,60184	-2.80627	-3,88892	-8.65203	-10,4713	0.241703
«EXPORT TO SPREADSHEET»	14063	-3,32659	-10,2051	-0,302034	-2,717	-2,94905	-4,18733	-9,10813	-10,6266	0,241968
(EAFURI IU SPREADSHEEI)	10083	-3,36437	-10,2836	-0,42189	-2,82603	-3,08371	-4,48859	-9,54929	-10,7691	0,24293
0,08	541606	-3,28852	-10,2807	-0,550106	-2,92437	-3,20793	-4,79231	-9,97533	-10,8979	0,244881
	873206	-3,36641	-10,359	-0,685033	-3,02687	-3,33143	-5,09731	-10,387	-11,0126	0,248124
-0,*	125464	-3,36656 -3,44313	-10,3974 -10,4767	-0,812697 -0,936618	-3,12345	-3,44959	-5,40156	-10,7837	-11,1125	0,252794
	163608				-3.21934	-3,56656	-5.70421	-11.1651	-11.1966	0.259002

FastTracer Software Excel Reporting (2) - Calculation



FastTracer Software Excel Reporting (3) - Caluclation



FastTracer Software Excel Reporting (4) - Caluclation



FastTracer Software RMS ISO10816



Within the software RMS of velocity is calculate in compliance with ISO 10816, the standard to asses vibration level on machinery



FastTracer Software Trigger View

In order to explore the resonance frequency of a structure the trigger view analysis is provided within FastTracer. With this analysis it's immediate to perform «Bump» test. Since FT it's a triaxial accelerometer, resonance along all the X,Y and Z direction could be explored with a single measure.



FastTracer Software

All the analysis option are available in real time and at the same time within the software. Furthermore it's possible to register the data and analyze them off-line in post processing.



APPLICATION HED

Vibration problems may arise into different industrial area such as civil industry, railways and train, naval industry, automotive, aerospace, wind energy, pumps, generators.



FastTracer rappresent the ideal solution whenever:

Portability, reliability and semplicity of use are a mustExpert operators are not required

- •Cost of solution it's an issue
- •Data exchange it's vital

Predictive maintenance of machinery, first troubleshoting of vibrations problems, simple conditiont monitoring system rappresent the ideal field where FastTracer should be used



MERAION TROLELESHOOTING AND MANTENANCE WITH FAST FRACER

AC/DC Motor / Generator





MERGION TROLELESHOOTING AND MANENANCE WITH FAST FACER

Problems







Normal condition







Problem Identification









CLIMMINS POWER STATION DI AGNOSTIC

 $\mathbf{\nabla}$

status

Cummins Generator Technologies is the manufacturer of the world's broadest range of ac generators from 0.6 to 20,000 kVA

CUMMINS Customer Issue

X

Needs of vibration measurement on the

field Traditional systems can be difficult for use[✓] × and transport

Requirements of a quick idea of machine status before to perform and invest in detailed investigations



SEQUOIA Solution: FastTracer

Portable and compact vibration analyser $\mathbf{\nabla}$ $\mathbf{\nabla}$ User Friendly software adapted for not expert people

PC interface doesn't require additional training

> Immediate FFT analysis and machine knowledge

CUMMINS Customer Benefits

Reducing costs of service and diagnostics operations

I Historical data archiving and comparisons

"...the capability to get basic vibration data during any visit our service team attends."

Scott Whiteside **Cummins Generator Technologies Global Mechanical & Vibration Specialist**



CLISTOMER SLICCESS STORY

SERVICE & MANENANCE

One of the world's leading manufacturer of construction and mining equipment, diesel and natural gas engines and industrial gas turbines.

Customer Issue

Needs of High Temperature
 analysis for predictive maintenance
 operations on steam turbines

Portable and compact device for service people

Saving periodical calibration

⊠ costs



SEQUOIA Solution: *Fast*Tracer

- ✓ Triaxial portable USB solution
 ✓ Internal thresholds database adapted for customer machines
 - No needs of periodical calibrations
 - Simple procedure adapted for not expert users

Customer Benefits

 $\mathbf{\nabla}$

 $\mathbf{\nabla}$

 $\mathbf{\nabla}$

Predictive maintenance information

- Downtime reducing
- The chance to permit not expert people to perform accurate and repeatable analysis



CLISTOMER SLICCESS STORY



A unique features of *FastTrace*r it's the possibility to be connected wireless to the PC thanks to the *FastWi* option.

This feature, allowing comunication up to 100 m, allows, expecially with fixed installation, to measure point hardly accessible and where long cabling installation could be difficults.







Sec. 1



() sequoia

Several FastTracer unit could be connected thanks to the FastWi option to the company intranet and explored via a central station, developing a simple, reliable vibration condition monitoring system





AIOUC

Trafic induced vibration application

FastTracer 2g is particulary suited for civil industry vibration measurament

Explora3D (Beta Version)

One of the maior issue within vibration maintenance is the possibility of fast identify defects of measured machine and equipment.

With Explora 3D (*Beta version*) sequoia provide an interesting database free tool able associate to every machine:

Mesurement Point(s) – Graphical
 Measurement Condition and operator instruction
 Reference curves for fast comparison of measurement
 Automatic identification of the defects







FastTracer PA

*Fast*Tracer is deliverd with a complete set of library and example for full integration within NI LabVIEW and Microsoft programming tools (C++) allowing:

FT integration in Customized Test System

Regration into End-of Line Vib. Quality Control

Education Purpose





thank you for the attention

